



1. Place well ballast next to heat cable 4" from water proof end seal.
2. Secure 4 each Nylon wire ties equally spaced.
3. Slip heat shrink over heat cable, well ballast and wire ties.
4. Shrink heat shrink with hot air heat gun.
5. Install submersible heat trace in well.

Brass Well Ballast
1" Diameter
Weight 1.5 LBS.

Water Proof End
Cap